ASSEMBLY INSTRUCTION



Please read this before beginning assembly and follow instructions carefully

Important Safety Instructions:

- Please read this instruction carefully prior to assembly.
- Please ensure all parts and hardware are available in the package prior to assembly.
- Use the parts and hardware lists to identify each component included.
- Save all packaging material until the completion to avoid any accidental discarding of smaller parts or hardware.
- Care should be taken to avoid tipping while seated.
- This chair is designed for use on level ground only. Do not use on unlevel ground.
- This chair is a rocking style. When chair is in rocking motion ensure areas in front and behind are clear of pets, children and adults to avoid accidental trapping.

Assembly tips:

- Please align pre drilled holes accurately during installation.
- Please insert screws in the right angle.
- This product can be damaged if parts are not correctly assembled.
- Screw position +/- 3mm is an acceptable range because wood is flexible.



THANK YOU FOR PURCHASING

PARTS LIST

BACKREST	1PC	
FRONT LEG	2PCS	F1R F1L
BACKREST SUPPORT FRAME	2PCS	В
MIDDLE BACKREST CROSS BEAM	1PC	C2
ARMREST	2PCS	A1R A1L
ARMREST SUPPORT	2PCS	A
BASE LEGS	2PCS	B1R B1R
BASE BOTTOM SUPPORT	1PC	B4
SEAT SLATS	5PC	B5
FRONT SEAT SLAT	1PC	B3
BACK LEGS CROSS BEAM	1PC	B2
ARMREST CONNECTION	2PCS	D 🕽
FRONT LEG CROSS BEAM	1PC	F2
RUNNER	2PCS	

HARDWARE LIST

a	*)	SCREW 3.5x35mm	40pcs+3 extra
(b)		BOLT 6x45mm	16pcs+1 extra
(C)		BOLT 6x55mm	2pcs+1 extra
d		WRENCH	1pc
e	*)	SCREW 3.5x25mm	10pcs

TOOLS REQUIRED (not included):

- > Drill with Cross Head Bit or Philips screwdriver
- > Adjustable Wrench

Care & Maintenance

- Do not put hot items directly on furniture surface.
- Do not clean furniture with harsh cleansers or polish.
- To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- Children should not climb or jump on the furniture.
- L Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- Not for commercial use. For residential use only.
- Stains may be removed with mild soap solution and damp cloth.
- Dust and pick-up spills using a clean, non-colored, lint-free cloth.





The Adirodack Chair is made with natural material - Pine Wood.

Recommendation: Place the chair under the shade or partial sun area.


Do not expose the chair to the sun to maintain the color and life span of the natural wood material.

Step 1 Difference of the state of the state






Step 4



Step 5



Step 6

