ASSEMBLY INSTRUCTIONS FU 0 M Ρ

ST CAB HALE

A Π

ſ

A	В	С	D	Е	F	G
	FR			\$ 111)	≪ccccccc_≬	
16 PIECES	16 PIECES	12 PIECES	4 PIECES	4 PIECES	4 PIECES	8 PIECES
Н	I	J	к	L	М	
	K	Ċ	()JJJJ-			
4 PIECES	2 PIECES	1 PIECE	1 PIECE	1 PIECE	2 PIECES	





X1











X2



X1



⁶10

X2



X1

6

12

14

X1





X1

13



X1













Fitting J should be used to secure your ST CAB HALE to the wall. Screws and fittings for wall are not supplied as different wall constructions require fittings that are suitable for your wall type. If you are unsure for the correct type of fitting for your wall, please contact your local specialised hardware store for information on suitable fitting.

13.