



Cross head Screwdriver also required for assembly

To prevent scratching:Lay the parts face down on a clean, flat, soft surface.



1



2.

