

Copenhagen Chair



Please read these instructions very carefully before you begin to ensure that your Futon Company Copenhagen Chair will give you many years of satisfaction.

Thank you for buying a Futon Company product.

We are constantly striving to improve everything we do, but occasionally mistakes do occur. In the unlikely event that you find any part missing, please call your nearest Futon Company store and we will arrange for the despatch of an immediate replacement. Please keep all packaging until you have checked every part and assembly of your Futon Company product is complete.

Version: 1

Product Code: CHAIR COPENHGN


PO 12472

experts in small space living



Part Checklist

Please count and check every component very carefully before you begin



1. Back Rest x 1



2. Seat Frame x 1



3. Seat



4. Left Leg (L) x 1



5. Right Leg (R) x 1



6. Rail x 2



Fittings Checklist

Please count and check every component very carefully before you begin

A



Allen Key x 1

B



Bolt x 4
(80mm size)

C



Bolt x 4
(60mm size)

D



Bolt x 2
(45mm size)

E



Spring Washer x 10

F



Flat Washer x 10

G



L Bracket x 4

H



Screw x 8
(16mm size)

I



Screw x 4
(35mm size)

J



Felt Pad x 4



How to assemble Copenhagen Chair


Please follow these instructions carefully

1. To prevent scratching :


Lay the parts face down on a clean, flat, soft surface.

Do not tighten the bolts and screws until the chair is fully set up.

2.



3.







How to assemble Copenhagen Chair

Please follow these instructions carefully

4.



5.







How to assemble Copenhagen Chair

Please follow these instructions carefully

6.



7.






How to assemble Copenhagen Chair

Please follow these instructions carefully

FUTON
C O M P A N Y

8.



Please make sure that all fittings are now fully tightened.

FINISH

Timber may be selected to ensure that the visible surfaces are of a higher grade than unseen surfaces. These unseen areas are not finished to the same standard as visible surfaces.

CARE

To clean your chair, wipe with a damp cloth followed by a dry cloth.

IMPORTANT

To ensure maximum performance from this product, we advise that you check and tighten all bolts and screws on a regular basis to avoid damage and strain to parts.

Improper use, improper assembly and mishandling may lead to product damage.

DO NOT STAND ON THIS CHAIR

GUARANTEE

This instruction leaflet forms part of your guarantee, please retain it. The PO number along with your invoice number will need to be quoted in all correspondence with

Futon Company.

Thank you for choosing Futon Company.

