


Assembly Instructions


Chest of Drawers

FUTON
C O M P A N Y
Experts in small space living


ST COD RIA




Parts Checklist




①x1




②x1




③x1




④x1




⑤x1




⑥x1




⑦x1




⑧x1




⑨x1




⑩x1




⑪x1




⑫x3




⑬x3



⑭x3



⑮x3




⑯x3



⑰x4

Fittings Checklist




(A) Cam Screw x 27




(B) Cam Lock x27



Ø6x30mm
(C) Wooden Dowel x16




Ø4x40mm
(D) Screw x14



(E) Panel Wedge x12




Ø3x14mm
(F) Screw x12



(G) Felt Pad x4




Ø3x12mm
(H) Screw x24




Ø4x30mm
(I) Screw x15




Ø4x12mm
(J) Screw x2




(K) Wall leash x2




(L) Wall Plug x2




(CL) Drawer Runner x3



(CR) Drawer Runner x3









(DL) Drawer Runner x3




(DR) Drawer Runner x3


To prevent scratching:Lay the parts face down on a clean, flat, soft surface.









3.




4.




5.




6.




7.






8.








9.



10.







Follow this step to fix your product to the wall. Fixing to secure your Cabinet to the wall is standard fitting. For details on suitable fixing for your wall type seek advice from your local specialised hardware store.

For safety reasons, we advise you to fix this item to the wall. Never allow children to climb on furniture.

