
Assembly Instructions



Storage - Mirage Pine Under Bed Drawer

ROPO no:





Thank you for buying Futon Company product

We are constantly striving to improve everything we do, but very occasionally mistakes do occur.

In the unlikely event that you find any part missing please call your nearest Futon Company store and we will arrange for the despatch of an immediate replacement.

Please keep all packaging until you have checked every part and assembly of your Futon Company product is complete.

Version number: 1 Product code: \$T DRW MIRAGE Date: 01/08/21


experts in small space living

\triangle

Parts Checklist

Please count and check every component very carefully before you begin

- 1 Drawer Back x 2
- 2 Right Side x 2
- 3 Left Side x 2
- 4 Base x 2
- (5) Drawer Front x 2





Fittings Checklist

Please count and check every component very carefully before you begin





- (a) Wooden Dowel x 16
- **b** Bolt x 8
- © Pressure Plate x 8



Allen Nut x 8



© Small Spanner x 1




How To Assemble Your Drawer

Please follow these instructions carefully

For parts 2,3+5 screw metal thread (part B) into metal insert and place wooden dowels into holes either side.

fixed, make sure Part 4 is


right in the groove.



Note: Before Part 5 is







FINISH

Timber may be selected to ensure that the visible surfaces are of a higher grade than unseen surfaces. These unseen areas are not finished to the same standard as the visible surfaces.

CARE

To clean your drawer, wipe with a damp cloth followed by a dry cloth.

IMPORTANT

To ensure maximum performance from this product, we advise that you check and tighten all bolts and screw on a regular basis to avoid damage and strain to parts.

GUARANTEE

This instruction leaflet forms part of your guarantee. Please retain it. The ROPO number along with your invoice number will need to be quoted in all correspondence with Futon Company.

Thank you for choosing Futon Company.