


BD4 LARK ASSEMBLY INSTRUCTIONS PO11488






Please read these instructions very carefully before you begin, to ensure that your Futon Company bed will give you many years of satisfaction.

Thank you for buying a Futon Company product. We are constantly striving to improve everything we do, but very occasionally mistakes do occur. In the unlikely event that you find any part missing, please contact your nearest Futon Company store and we will arrange for despatch of an immediate replacement.


Please keep all packing until you have checked every part and assembly of your Futon Company product is complete;


PARTS CHECKLIST





FITTINGS CHECKLIST


Label	Picture	Description	Qty	Label	Picture	Description	Qty
Α		Bolt M8 x 25MM	20	E	<u> </u>	Corner Plate	2
В		Bolt M8 x 35MM	4	F	8	End Plate	2
С	J	Bolt M8 x 55MM	8	G		Leg	4
D		Allen Key M5	1				











CARE INSTRUCTIONS

To protect and care for your bed, we suggest the following cautions:

Position the bed at least 50 cm from sources of heat such as heaters or radiators.

Avoid exposing the bed to direct sunlight or to powerful lamps to ensure the colour of the covering remains bright.

Avoid jumping on the bed and do not throw yourself violently onto the bed.

Do not drag the bed over rough surfaces(carpets, wall to wall carpets, etc) and if the bed has to be moved, it must be lifted and not pushed, even when on smooth surfaces.

Don't pull loose threads, cut them instead.

To remove dust from your fabric bed, brush delicately using a brush with soft bristles, or use a vacuum cleaner at a medium power setting using the most suitable accessory supplied with the cleaner and taking care not to rub the accessory directly on the covering.

To maintain the aesthetic appearance it is advisable to treat each stain before it is absorbed: this will avoid prolonged or abrasive treatments being required.

If it is found necessary to use solvents, avoid applying the solvents directly on the stain. Pour the solvent onto a clean cloth: each treatment should first be tested on a hidden area of the bed. Use of detergents for washing dishes or similar detergents is not recommended because residues may be deposited on the covering fibres.

Clean the stain by adopting a circular movement, working from the outside towards the centre. Always take care to rub each stain delicately.

If you purchase a new bed, with a covering that is an identical article and/or has the same colours as a bed that you already own, it is possible that you may note slight differences in shades of color between the two.